




spacing of tracks for 18mm board



Screws 1 and 2 should be fastened before door installation.





Screws 3, 4 and 5 should be fastened after door installation and regulation


Use template when installing the carriages.

**ATTENTION!**



With doors higher than 150 cm, we recommended the use of angle section K2 decor for aesthetic reasons and in order to secure the door from dismounting.



## COMPONENTS





Length  
1.7 m, 2.35 m, 3.0 m.



Length  
1.7 m, 2.35 m, 3.0 m.



Dimensions of opening



door filling - #18 mm board

door height	- h	$h = H - 13 \text{ mm}$
board height (1 mm ABS edging)	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = ( W + Z ) : N$
board width (1 mm ABS edging)	- wb	$wb = w - 2 \text{ mm}$

number of doors	- N	2	3
total overlap	- Z	30 mm	60 mm

visual design - 4 wings	
 door set up	$w = ( W + 90 ) : 4$
 door set up	$w = ( W : 2 + 30 ) : 2$

**ATTENTION !**

When cutting the board, you need to include the thickness of ABS edging. On our calculation 1mm ABS edging was used.

**ATTENTION !**

System Micra can be used in conjunction with any of SEVROLL's handle profiles suitable for 18mm fillings.